



NOTES:

1. IF FLUME IS 7' OR WIDER, USE REMOVABLE PIPE BOLLARDS 7'X6" DIA., AND FILL WITH CONCRETE. PLACE AT BOTH START AND END OF FLUME, BURY TO 4' DEPTH.
2. SIDE SLOPES TO BE HYDROMULCHED. ADD GROUTED ROCK RIPRAP AT BENDS, AND HIGH VELOCITY AREAS, ETC. WHERE NECESSARY
3. CROSS FENCING NOT ALLOWED, UNLESS APPROVED BY CITY ENGINEER. ALL APPROVED CROSS FENCING SHALL BE WROUGHT IRON TYPE.



STORM DRAIN CONSTRUCTION DETAILS  
CONCRETE FLUME

REVISION DATE:  
2/1/2024

SHEET: D-05